



AA-420 Construction BOM



AA-420 Construction BOM

Item	Number	Description	Quantity	Item	Number	Description	Quantity
1	4301-110025-C	Bolt	8	22	3503-113DA	Spacer Ring	1
2	3503-1101A	Discharge Cover Plate	1	23	4101-7310BUO	Bearing	2
3	4307-DB080	Disc Spring	1	24	4302-250	KM Nut	1
4	3503-1111A	Bearing Spacer	1	25	3503-1109AB	Bearing Spacer	1
5	4302-240	KM Nut	1	26	4307-DB100	Disc Spring	1
6	4101-7308BUO	Bearing	2	27	4102-NJ2206E	Bearing	1
7	3503-113AA	Spacer Ring	1	28	35303-1133BE-A	Female Rotor	1
8	35303-1137AB	Spacer Ring	1	29	4102-NU312E	Bearing	1
9	4102-NU2308E	Bearing	1	30	3502-1164A	Parallel Key	1
10	35303-1131BG	Bearing Seat	1	31	35303-1132BE-A	Male Rotor	1
11	4305-924	Plug	9	32	4301-106012-C	Bolt	6
12	35302-1102AB	Parallel Pin	4	33	3504-1161D	Seal Cover	1
13	4305-927	Plug	1	34	4201-VG095	O-Ring	1
14	35303-1163AG	Front Cover Plate	1	35	4203-060080L	Shaft Seal	1
15	4301-110035-C	Bolt	9	36	4201-VG050	O-Ring	1
16	4201-VP020	O-Ring	1	37	4807-02	Bush	1
17	35303-1141CE	Housing	1				
18	4201-VP012	O-Ring	1				
19	4301-110045-C	Bolt	10				
20	4102-NU310E	Bearing	1				
21	35303-1134AB	Spacer Ring	1				

AA-420 I=X,XX Construction BOM



AA-420 I=X,XX Construction BOM

Item	Number	Description	Quantity	Item	Number	Description	Quantity
1	4301-110025-C	Bolt	8	26	35319-3115BA	Gear Key	2
2	3503-1101A	Discharge Cover Plate	1	27	4101-7211BECBP	Bearing	2
3	4307-DB080	Disc Spring	1	28	35319-31XXA	Gear	1
4	3503-1111A	Bearing Spacer	1	29	35319-3102AA	Spacer Ring	1
5	4302-240	KM Nut	1	30	4102-NU2206E	Bearing	2
6	4101-7308BUO	Bearing	2	31	3519-3119A	Spacer Ring	1
7	3503-113AA	Spacer Ring	1	32	3519-311AA	Fixed Plate	2
8	35303-1137AB	Spacer Ring	1	33	4301-110035-C	Bolt	9
9	4102-NU2308E	Bearing	1	34	4301-106016-C	Bolt	2
10	35303-1131BG	Bearing Seat	1	35	3506-1037A	Stop	2
11	4305-924	Plug	9	36	35319-1141AE	Housing	1
12	35302-1102AB	Parallel Pin	4	37	4305-105	Plug	3
13	4305-927	Plug	1	38	4201-VP012	O-Ring	1
14	4201-VP028	O-Ring	1	39	4301-110045-C	Bolt	10
15	3506-3117A	Conduit Coupling	1	40	4102-NU310E	Bearing	1
16	35319-3118AA	Adapter Sleeve	1	41	35303-1134AB	Spacer Ring	1
17	35319-3101AE	Gear Box	1	42	3503-113DA	Spacer Ring	1
18	4301-106012-C	Bolt	10	43	4101-7310BUO	Bearing	2
19	3504-1161D	Seal Cover	1	44	4302-250	KM Nut	1
20	4201-VG095	O-Ring	1	45	3503-1109AB	Bearing Spacer	1
21	4203-060080L	Shaft Seal	1	46	4307-DB100	Disc Spring	1
22	4201-VG050	O-Ring	1	47	35319-1133AC	Female Rotor	1
23	4807-02	Bush	1	48	35319-32XXA	Pinion Gear	1



Item	Number	Description	Quantity	Item	Number	Description	Quantity
24	3502-1164A	Parallel Key	1	49	35319-NU312E	Bearing	1
25	35319-3113BA	Gear Shaft	1	50	35319-1132BA	Male Rotor	1